



Luminescence Index Tracers for DIAMOND Applications

Product Code: DTLI

Calibrate and test X-Ray sorters

- 7 luminescence indices available
- 3 sizes available: 2mm, 4mm and 8mm



OPERATING PROCEDURE

Diamond Luminescence Tracers & Applications

Luminescence Index Tracers mimic diamonds in terms of density and are offered in seven luminescence levels to simulate the response to X-rays of high-luminescent and low-luminescent diamonds. Like diamonds, they should be translucent to light, so that the luminescence is a volume effect, not just a surface effect.

They are commonly passed through a sorter to provide a basis for adjusting the sensitivity of the photomultiplier tubes which detect the presence of diamonds. Those adjustments are usually made with no feed gravel passing through the sorter. It is important to also conduct tests with feed on to check for diamond losses which may result from overloading or other causes.

Luminescence Index Tracers are not designed for use as Spiking tracers. Such use would subject them to wear, which would increase their densities.

Luminescence Tracer Testing For Calibrating and Testing X-ray Sorters

The manufacturers of X-ray sorting machines recommend procedures for calibrating and testing their sorters. In an ideal world one might recover a large number of small and large diamonds from a deposit and characterize them all for luminescence response in a sorter with configuration similar to those to be employed in the plant. Armed with such knowledge for each size fraction, one could calculate a sorter sensitivity setting which would strike the best financial compromise between maximizing diamond recovery and minimizing concentrate contamination.

Such analyses are rarely conducted, but most operators realize that recovery can deteriorate rapidly as a result of wear on key components, buildup of dust, or factors which alter particle trajectories. Consequently it is important to test frequently.

One regime which may be useful with some classes of machine is as follows:



CALIBRATION

- 1** Select a size of LI tracer within the feed size range for the sorter to be tested.
- 2** Select a luminescence value corresponding to diamonds from your deposit which you would not wish to lose.
- 3** At the start of each shift, turn off feed to each machine and conduct routine cleaning and adjustment.
- 4** Introduce 20 tracers to one channel of the machine.
- 5** If some report to rejects*, increase sensitivity (usually photomultiplier voltage) slightly and repeat the test. If none report to rejects, slightly reduce sensitivity and repeat the test.
- 6** Continue making small adjustments to find a sensitivity which is just sufficient to recover all 20 tracers.
- 7** Repeat the procedure for each channel in each sorter.

* The number reporting to rejects may be monitored in a number of ways:

- A counter will indicate the number of detections, and listening for the ejector and the rattle of the tracer may indicate whether it was successfully ejected and will later report to a glove box.
- For these offline tests, some users fit a removable basket to the ejection leg of the sorter, so that a clear result is immediately available. Tracer losses are limited to only those which were not ejected.
- In statistical terms, a binomial test which yields 20 successes from 20 trials indicates that one may be 95% confident that the underlying probability of recovering diamonds with the selected luminescence, exceeds 86 percent.



LOAD TESTING

For a number of reasons, including masking by non-luminescing particles, or alteration of trajectories, ejection when feed is on may not be reliable. Tests may be routinely conducted to assess the effects of feed load. A test may involve the addition of 100 tracers of the size and LI value normally used for calibration of the machine in question. Baskets cannot be used, and the result may have to await completion of sorting in the glovebox. If the recovery rate is significantly below that indicated by the calibration procedure, it may be appropriate to reduce feed rate to the sorter in question.

If more than one sorter is tested using the same tracer size and LI value, test schedules should be co-ordinated to avoid confusion over which tracers arrive at the glove box at what time. For sorters which treat coarse gravel, where diamonds are rarely found, it may be feasible to generate a rapid result, relying only on the number of logged detections.



PRECISION TRACERS FOR DMC OPTIMISATION

Density Tracers for Diamond Applications offer the following:

Certified	Each shipment includes Quality Control Certificates for accuracy of luminescent levels.
Discounts	5% discount where 500 or more of the same item are ordered eg. 500 x 8mm LI 100 Violet. 2.5% discount for pre-payment at the time of ordering.
Non Toxic	Contain no lead compounds.
Ferromagnetic	Are ferromagnetic to facilitate retrieval from plant streams or in the lab.
Luminescent	Seven levels of X-ray luminescence.
Translucent	Translucent to light, so luminescence mimics that of a diamond, making them suitable for all classes of X-ray sorters.
Hydrophobic	Hydrophobic for recovery on grease tables or belts.
Density	Approximately 3.53 g/cc so that they will pass through a sorter following trajectories similar to those of diamonds.
Nonmagnetic	Are nonmagnetic to avoid problems in circuits which incorporate magnets.
Fast Delivery	Common sizes couriered to your store in 1-2 weeks.
No Hidden Costs	Prices include packaging and handling. Freight will be advised in an emailed quotation, where applicable.
Credit	For many clients we accept 30 day payment terms.





DIAMOND TRANSLUCENT LUMINESCENCE INDEX TRACERS Product Code: DTLI

Export Price AUD

LI Level & Colour Code	2mm Tracer size	4mm Tracer size	8mm Tracer size
LI 100 Violet	-	\$4.46	\$8.06
LI 50 Pink	-	\$4.46	\$8.06
LI 25 Brown	\$3.34	\$4.46	\$8.06
LI 12.5 Blue	\$3.34	\$4.46	\$8.06
LI 6.25 Green	\$3.34	\$4.46	\$8.06
LI 3.13 Yellow	\$3.34	\$4.46	\$8.06
LI 1.56 Orange	\$3.34	\$4.46	\$8.06

www.partitionenterprises.com.au
pe@partitionenterprises.com.au
1800 367 765 +61 7 3054 590

References

Davis, JJ, Wood, CJ and Lyman, GJ, 1985a, "Density Tracers Can Improve Coal Preparation Plant Yield", Australian Coal Miner, July, pp9-11.

Davis, JJ, Wood, CJ and Lyman, GJ, 1985b, "The Use of Density Tracers for the Determination of Dense Medium Cyclone Partitioning Characteristics", Int. J. of Coal Processing, 2(2) 107-126.

Davis, JJ, Wood, CJ and Lyman, GJ, 1985c, "The Effects of Operating Variables on Dense Medium Cyclone Operation", Proceedings, Third Australian Coal Preparation Conference, Wollongong.

Wood CJ, Davis, JJ and Lyman, GJ, 1987, "Towards a Medium Behavior Based Model for Coal-Washing Dense Medium Cyclones", Aus IMM Dense Medium Operators' Conference, Brisbane, 1987, pp247-256 and Coal Preparation, 1989, Vol 7, pp183-197.

Wood, C.J., 2004. "Density Tracer Testing of Coarse Coal Separators: Suggestions for an Australian Standard", in Membrey, WB(ed), Proceedings, Tenth Australian Coal Preparation Conference, Paper E12.

